



N. CODE	DESCRIPTION	N. CODE	DESCRIPTION	N. CODE	DESCRIPTION	N. CODE	DESCRIPTION
1	11.2064	56	16.7168	111	22.3656	166	27.7387
2	28.9739	57	27.2347	112	CONICAL SPRING	167	SPECIAL WASHER
3	28.9738	58	16.3701	113	SPECIAL WASHER	168	SEEGER 20 SW
4	12.1351	59	12.6266.0.57	114	SEEGER 19 SW	169	5TH GEAR - LAYSHAFT
5	27.2520	60	16.5360	115	SPECIAL WASHER	170	WASHER 18x27x0.8
6	27.4710	61	29.1029	116	GASKET 16x22.5x1	171	1ST GEAR - LAYSHAFT
7	11.5548	62	29.1003	117	FEEDING OIL PLUG	172	NEEDLE BEARING 18x22x10
8	29.1196	63	10.6734	118	WARNING OIL PLUG	173	WASHER 15x25
9	16.4950	64	10.6734	119	OIL SEAL	174	BALL BEARING 15x35x11
10	29.1214.0.57	65	12.6311.0.57	120	OUTER CLUTCH	175	SHIFT LEVER
11	10.6726	66	31.3451	121	SCREW 6x20	176	OIL SEAL 12x22x5
12	10.6727	67	10.6773	122	WATER PUMP SHAFT	177	NEEDLE BEARING 12x18x12
13	16.8070	68	12.9342	123	BALL BEARING 10x22x6	178	WASHER 12x22
14	12.5184.0.57	69	12.9341	124	SCH. BALL BEARING 10x22x6	179	SPECIAL NUT 16x1.25x6
15	16.6176	70	10.4461	125	OIL SEAL 10x18x4	180	SHIFT CONTROL SPRING
16	16.3355	71	31.2184	126	PUMP FAN	181	SHIFT CONTROL FORK
17	13.2711	72	10.6736	127	SPECIAL O-RING	182	ROLLING SHIFT CONTR. FORK
18	27.5776	73	12.6793.0.57	128	PUMP COVER	183	PIN FOR RETURNING SPRING
19	27.5776	74	31.3000	129	SCREW 5x16	184	SELECTOR SHAFT
20	10.6466	75	16.4750	130	SPECIAL SCREW 6x7	185	SELECTOR SPRING
21	12.9986	76	28.2266	131	GASKET 6x12x1.5	186	WASHER 12x22
22	25.9808	77	27.7348	132	SEEGER 9E	187	NEEDLE BEARING 12x18x12
23	13.1712	78	11.2713	133	WASHER 20x35x1	188	SCREW 6x30
24	11.0372.8	79	12.2078	134	STEEL BUSH 20x25x20.5	189	TOP CAM
25	16.1670	80	27.6589	135	CLUTCH HOUSING	190	NEEDLE BEARING 30x37x12
26	28.9412	81	29.0962	136	SPECIAL WASHER CLUTCH	191	WASHER 30x38
27	25.8657	82	13.3836	137	CLUTCH CENTER	192	CAM
28	28.5220	83	13.4331	138	CLUTCH PLATE	193	WASHER 30x38
29	28.5220	84	12.2960	139	CLUTCH PLATE	194	NEEDLE BEARING 30x37x12
30	25.8657.8	85	22.6507	140	PRESSURE PLATE	195	LOCATING SPRING
31	10.4260	86	27.4200	141	CLUTCH SPRING	196	LOCATING LEVER
32	31.0214	87	11.4801	142	WASHER 6x18	197	SEEGER 10E
33	27.2349	88	25.5319	143	BOLT 6x16	198	SELECTOR FORK 28.5
34	22.3932	89	31.6388	144	DRIVE GEAR PIN	199	SELECTOR PIN 10x103.5
35	27.4050	90	16.1656	145	SCREW 8x15	200	SELECTOR FORK 34.5
36	31.3801	91	18.6782	146	NEEDLE BEARING 18x22x10	201	SELECTOR PIN 10x60
37	15.1538	92	27.7256	147	GEAR	202	SELECTOR FORK 32.5
38	28.2257	93	28.2530	148	WASHER 18x27		
39	21.2750	94	11.5452	149	SEEGER 18E		
40	12.0498	95	21.5517	150	BOLT 8x16		
41	11.6410	96	10.5800	151	KICKSTARTER LEVER		
42	29.0729.8	97	11.3105	152	DIL SEAL 16x24x5		
43	10.6466	98	27.6750	153	DIL SEAL 16x24x5		
44	12.9956	99	10.1513.8	154	SINTERED BUSH		
45	10.0067	100	10.1513.8	155	WASHER 16x25		
46	12.4600	101	16.1487	156	STARTER SHAFT		
47	16.4150	102	22.7897	157	NEEDLE BEARING 16x21x10 2P		
48	12.0629.0.57	103	31.3451	158	KICKSTARTER SPRING		
49	31.5901	104	13.1150	159	SCREW 6x20		
50	31.2983	105	27.7362	160	NUT 6x3.5		
51	12.6971.0.57	106	28.2545	161	WASHER 20x30x2		
52	31.3451	107	27.7362	162	SEEGER 19 SW		
53	29.0045	108	18.1463.8	163	WASHER 20x30x2		
54	16.5360	109	27.7386	164	STARTER GEAR		
55	16.5573	110	28.2545	165	SPECIAL WASHER		
			22.1410.8		SEEGER 19 SW		
					KICKSTARTER SLEEVE		

SUPPLEMENTARY PARTS LIST

12.0073.8	GEARBOX
22.0505.8	COMPLETE KICKSTARTER
28.0687.8	OIL SEAL SET
28.0808.8	GASKET SET

N. CODE	DESCRIPTION	N. CODE	DESCRIPTION	N. CODE	DESCRIPTION	N. CODE	DESCRIPTION
1	21-2706 FRONT BRAKE LEVER ONLY	60	12-3218 BUMPER	119	12-9830 CONICAL BEARING	178	22-4700 SPRINGS
2	21-0208 FRONT BRAKE LEVER	61	16-2332 BUMPER RUBBER	120	29-0202 PLATE	179	15-1430 CLAMP
3	16-5051 COPPER WASHER 10x15x1	62	29-1624 EXHAUST PIPE	121	29-1128 FRONT FRAME	180	16-2949 GROMMET
4	29-0911 FRONT BRAKE HOSE	63	10-6710 OIL SEAL	122	12-9830 CONICAL BEARING 20x42x15	181	12-3993-0-66 STAND
5	22-1860 GRIP	64	10-6710 OIL SEAL	123	28-9732 REGULATOR COVER BRACKET	182	29-1186 CHAIN TENSIONER
6	12-5503 THROTTLE KIT	65	11-6396 BOLT	124	27-2807 REGULATOR	183	12-8147 TIRE 18 TUBELESS
7	12-5596 TWIST GRIP COVER	66	15-1523 CLAMP	125	12-8851-0-75 TANK COVER	184	12-4292 RIM 18 TUBELESS
8	29-1478-0-52 THROTTLE CABLE	67	29-1586 RADIATOR TUBE	126	29-1051 TANK PLUG	185	31-1000 TUBELESS VALVE
9	16-2359-0-53 HANDLEBAR RUBBER	68	11-2728 BUSH	127	29-0140 RADIATOR CAP	186	25-5692 REAR WHEEL AXLE
10	13-3664 SWITCH	69	18-8351 GREASE NIPPLE	128	12-0939 ELECTRONIC SPEEDOMETER	187	13-8573 WHEEL HUB SH SPACER
11	18-0149 ELECTRIC EQUIPMENT	70	11-6300 BOLT	129	28-9516 SPEEDOMETER BRACKET	188	25-9876 BEARING PROTECTION
12	22-1850 GRIP	71	11-1973 CONNECTING ROD	130	28-0158-0-52 SEAT	189	12-9801 BEARING
13	21-0242-9 CLUTCH LEVER ONLY	72	28-9312 SPHERICAL BUSH	131	31-3054-0-52 VITE TTCJC 6x16 T15	190	12-8828-0-52 REAR DISK BRAKE COVER
14	21-0242 CLUTCH LEVER	73	10-6645 OIL SEAL	132	28-8560 LIQUID TANKER	191	11-4901 BOLT 6x20
15	16-5051 CLUTCH CABLE	74	11-2884 BUSH	133	15-1524 CLAMP	192	27-5751 WASHER 6x18
16	29-0909 HYDRAULIC CLUTCH HOSE	75	31-6397 SCREW	134	29-1587 UPPER RADIATOR TUBE	193	22-3198 SPRING
17	22-2045 HANDLEBAR	76	13-4770 SPACER	135	28-9529 OIL TANK FIXING BRACKET	194	13-6200 BRAKE DISK SPACER
18	13-4616 SPACER	77	27-5400 WASHER	136	28-0510 BRAKE OIL TANK	195	13-3928 REAR BRAKE DISK
19	16-4703 DCTICAL GROUP	78	11-6390 BOLT	137	28-9534 EXHAUST FIXING BRACKET	196	13-6271 WHEEL HUB INNER SPACER
20	22-2846-0-69 HEADLIGHT HOLDER	79	31-6561 SCREW	138	28-9194 SILENT BLOCK	197	22-0799 REAR HUB
21	21-1559 LAMP	80	27-5400 WASHER	139	27-7995 PETCOCK	198	12-8943 REAR SPROCKET
22	21-1564 LAMP	81	13-4760 SPACER	140	31-3056-0-52 SCREW 6x20	199	12-8486-0-52 CHAINGUARD
23	25-2522-0-52 GUIDING SLIT BREAK HOSE	82	11-2787 NEEDLE BEARING	141	25-1961-0-75 REAR FENDER W/DECALCS	200	12-0677 CHAIN
24	25-1517-0-53 FRONT FENDER W/DECALCS	83	10-5400 OIL SEAL	142	12-7321-0-52 FILTER COVER	201	22-1122 CONNECTING LINK
25	25-9893-0-53 RH FORK TUBE PROTECTION	84	11-2251 NEEDLE BEARING	143	15-2605 AIR FILTER	202	13-2960 REAR WHEEL NUT
26	28-9838 FENDER BRACKET	85	11-2038 CONNECTING ARM	144	28-1274-0-52 BOX AIR FILTER	203	27-7121 WASHER
27	23-1010 NIPPLES	86	31-2153 FLAN	145	15-1538 CLAMP	204	13-8572 WHEEL HUB RH SPACER
28	27-2419 FRONT SPOKE	87	14-0101 COMPL. ELECTRIC FAN	146	22-1364 RUBBER SLEEVE	205	25-9876 BEARING PROTECTION
29	15-0801 FORK	88	28-9801-0-52 ELECTRIC FAN BRACKET	147	28-9186 SILENCER	206	12-9801 BEARING
30	12-4650 EXPANDER RIVET	89	22-9005 FOOTREST HUB	148	12-5432-0-59 SILENCER TAIL	207	11-6502 FEELER COVER BOLT
31	11-6504 SPEC. BOLT BRAKE TUBE	90	25-5445 BRAKE PEDAL PIN	149	16-2960 SILENCER GROMMET	208	27-2496 REAR SPOKE
32	31-2982 SCREW 5x16	91	22-6209 RET. BRAKE PEDAL SPRING	150	29-1129 REAR FRAME	209	23-1003 SPECIAL NIPPLES
33	25-9894-0-53 LH FORK TUBE PROTECTION	92	22-6217 RET. BRAKE PEDAL SPRING	151	10-6668 OIL SEAL	210	11-6504 SPEC. BOLT BRAKE TUBE
34	29-0911 FRONT BRAKE HOSE	93	11-2661 BRAKE LEVER BUSH	152	10-6668 OIL SEAL	211	29-0912 REAR BRAKE HOSE
35	16-5051 COPPER GASKET	94	25-2807 BRAKE PEDAL	153	12-8841 MUFFLER COVER	212	16-5051 COPPER WASHER 10x15x1
36	25-0304 FRONT BRAKE PLIERS	95	28-9313 PUMP PIN W/SPRING	154	22-0335 MUFFLER	213	25-0306 REAR BRAKE PLIERS
37	13-8545 WHEEL HUB RH SPACER	96	10-8450 REAR BRAKE RHD	155	28-9194 SILENT-BLOCK	214	14-4001 FIXING GROMMET
38	25-9876 BEARING PROTECTION	97	25-9117 REAR BRAKE PUMP	156	11-5570 BOLT		
39	12-9801 BEARING	98	16-5051 COPPER WASHER 10x15x1	157	13-4653 SPACER		
40	22-0719 FRONT HUB	99	11-2640 BUSH	158	22-6202 FOOTREST SPRING		
41	12-8826-0-53 FRONT DISK BRAKE COVER	100	25-9992-0-52 TANK PROTECTION -KIT-	159	25-3305 LH FOOTREST		
42	13-6270 WHEEL HUB INNER SPACER	101	25-3300 R/H FOOTREST	160	28-9926 LH FOOTREST BRACKET		
43	13-3927 FRONT BRAKE DISK	102	22-6201 FOOTREST SPRING	161	11-5450 BOLT		
44	13-6200 BRAKE DISK SPACER	103	28-9925 RH FOOTREST BRACKET	162	11-5545 BOLT		
45	22-3198 SPRING	104	11-2850 SPACER	163	10-0371 SHOCK ABSORBER		
46	27-5751 WASHER 6x18	105	28-9150 SILENT-BLOCK	164	13-1901 SELF-BLOCKING NUT		
47	11-4951 BOLT 6x25	106	11-4905 BOLT	165	27-5400 WASHER		
48	12-9801 BEARING	107	29-1588 RADIATOR TUBE	166	11-6371 BOLT		
49	25-9876 BEARING PROTECTION	108	15-1523 CLAMP	167	13-2951 S/ARM SPECIAL NUT		
50	13-8504 LH FRONT HUB SPACER	109	15-2341-0-53 LH RADIATOR COVER	168	27-6750 WASHER		
51	25-5691 FRONT WHEEL AXLE	110	15-2340-0-53 RH RADIATOR COVER	169	13-4920 SPACER		
52	15-1750 TIRE FASTENER	111	29-1134 LH FRONT FRAME	170	11-2300 S/ARM NEEDLE BEARING		
53	27-4800 WASHER	112	28-9194 SILENT-BLOCK	171	22-8111 SPRING		
54	13-1700 NUT	113	27-2363 RADIATOR	172	16-2250 CHAIN TENS. BLOCK		
55	12-7940 TIRE 2.75x21	114	10-0922 HORN	173	25-2595 SLIDING BLOCK		
56	12-1641 TUBE 2.75x21	115	16-4554-0-69 RADIATOR COVER	174	29-1008-0-52 SLIDING BLOCK		
57	15-3820 BEAD 21	116	29-1133 RH FRONT FRAME	175	15-4959 SWINGING ARM		
58	12-4253 RIM 21	117	10-6686 OIL SEAL	176	25-5577 S/ARM SPINDLE		
59	31-6395 SCREW	118	10-6739 DUST COVER RING	177	28-9857-0-66 STAND BRACKET		

SUPPLEMENTARY PARTS LIST

12-4303	SPARK KEY
12-4354	SPECIAL NIPPLES KEY
13-2182	NUT
13-3309	FORK DECALS
13-3382	SPONSOR DECALS
13-3395	FRONT LIGHT DECALS
13-3385	TANK DECALS
13-3391	REAR FENDER DECALS
13-3390	FRONT FENDER DECALS
13-3394	DECALC SET
15-0182	REAR LIGHT
18-0142	REAR LIGHT ELECTRIC EQ.
18-8700	STOP SWITCH
21-1552	WARNING LIGHT BULB
27-0254-4-57	FRONT WHEEL ASSY
27-0464-4-57	REAR WHEEL ASSY
28-9292	REAR VIEW MIRROR
28-9526	STOP SWITCH BRACKET